



Den Braven



APPLICATION GUIDELINES

Zwaluw FireProtect FP Acrylic Sealant

FP Acrylic Sealant can easily be applied with a professional caulking gun.

Situation A: Single or double sided sealing of the joint with FP Acrylic Sealant



1. Clean from dust with a soft brush and remove loose particles. When needed pre-treat the joints with a primer for porous substrates.



2. Place backer rod at the right depth.
Joint width/3 + 6 mm = joint depth
Example: 15mm/3 = 5+6mm = 11mm depth



3. Apply FP Acrylic Sealant to the backer rod and make sure the joint is completely filled with material.



Den Braven



4. Finish the joint with a brush, moistened with water.



5. Repeat steps 1 to 4 on the other side when the joint needs to be sealed on both sides.
6. The joint is now fire retardant and securely sealed with FP Acrylic Sealant.



Den Braven



Zwaluw FireProtect FP Acrylic Sealant

FP Acrylic Sealant can easily be applied with a professional caulking gun.

Situation B: Fill joint partly with FP PU Foam and finish with FP Acrylic Sealant



1. See application guidelines for FP PU Foam to apply the foam recessed, with result as beside picture.



2. Apply FP Acrylic Sealant to the cured FP PU Foam and make sure the joint is completely filled with material.



Den Braven



3. Finish the joint with a brush, moistened with water.



4. The joint is now fire retardant and securely sealed with FP PU Foam and FP Acrylic Sealant.